



序号	代号	名称	数量	序号	代号	名称	数量	序号	代号	名称	数量	序号	代号	名称	数量	序号	代号	名称	数量
1	GB/T61177-1-M6	螺母 Nut	5	36	3WF-2.6.7-6	压板 plate	1	60	GB/T971-8	垫圈 Plain washer	1	105	3WF-3.20.1	转向铰合 Strainer	1	135	3WF-3.19-5	水管卡子 clip	4
3	GB/T 96.2-6	垫圈 Plain washer	5	37	GB/T 845-ST4.2X13	螺钉 Screw	3	61	3WF-2.6.9.2	叶轮组合 Fan	1	106	3WF-2.6.2-1	油箱 Fuel tank	1	136	SG79-10X2	管 Water tube	0.85m
4	3WF-2.6.10-1	机架 Frame	1	38	3WF-2.6.9-1	风机网罩 Net cover	1	62	3WF-2.6A.7	支撑柱组件 support component	2	107	1E40FC.1-2	油网密封胶 Gasket	1	137	3WF-3.19.1	开关组合 cock assem	1
5	3WF-2.6A.6	减震柱组合 Rubber column	3	39	3WF-2.6A-3	前门体密封胶 body gasket	1	72	GB/T 818-M5X35	螺钉 Bolt	10	108	1E40FC.1.1	油网铰合 Strainer	1	138	SG79-10X2	管 Water tube	0.65m
6	GB/T9074.4-M5X20	螺钉组合件 Bolt	2	40	3WF-3-9	密封胶 washer	1	73	3WF-2.6.9.3	前盖壳组合 Worm case	1	109	SG79-8X2	管 Water tube	0.4m	139	ZB4-5-02	大软管 Hose	1
7	3WF-2.6B.4	底座撑组合 support	1	41	3WF-2.6.6-1	下轴管 pipe	1	74	GB/T845-ST4.8X32-F-H	螺钉 Screw	4	110	3WF-3.17.1-3	药箱密封胶 Gasket	1	141	3WF-2.6A.4.1	3号卡环组件 Clamp	1
8	3WF-3-18	连接垫 link washer	2	42	3WF-3-8	盖 lid	1	75	3WF-3-19	防尘罩 Cylinder cover	1	111	3WF-3.17.1-1	进气嘴 Air valve	1	145	3WF-2.6.4.1	接头组架 connector	1
9	3WF-2.6B-2	背垫卡子 Clip	5	43	GB/T 845-ST4.2X13	螺钉 Screw	3	76	GB/T 96.2-8	垫圈 Plain washer	2	112	3WF-3.17.1-2	药箱盖 Spray tank cap	1	146	3WF-2.6.4-2	长管管 pipe	1
10	3WF-2.6.8	背垫部件 Pad	1	44	3WF-3.6-3	消板销 pin	1	77	GB/T 6170-M8	螺母 Nut	2	114	3WF-F8-9.03	油箱盖组合 Fuel tank cap	1	145,146	3WF-2.6	管组合 pipe	1
11	EB-4.15.16-2	拉环 Pull loop	2	45	3WF-3.6-2	橡胶盖板 rubber plate	1	80	GB/T5783-M8X75	螺栓 Bolt	2	115	1E40FC.1-4	塑料内盖 Inner cap	1	147	GB818-M5X25	螺钉 Bolt	2
13	3WF18-3-05-04	背带部件 Belt	1	46	WF-3.6-1	消板 slide	1	82	3WF-2.6A-1	夹紧板 clamp	2	116	1E40FC.3A.3-3	滤芯 filter lid	1	148	3WF-2.6.4-8	提把 handle	1
15	3WF-3.26.3	套筒扳手 spanner	1	47	3WF-3.6-4	支撑臂 support arm	1	84	GB/T 9074.4-M5X35	螺钉组合件 Bolt	4	117	1E40FC.1-3	橡胶内盖 rubber lid	1	149	ZB4-5-4-01	手把卡环 Clamp	1
16	3WF-3.26-1A	拉拔器扳手 diasassembly	1	48	GB/T 896-4	挡圈 ring	1	85	3WF-3.7-2	喷射盖板 dusting plate	1	118	3WF-2.6A.1-4	药箱下盖 Spray tank cap	1	150	3WF-2.6.4.3	喷头组架 Nozzle	1
23	3WF-2.6.7.2	油门操纵杆 throttle rod	1				86	3WF-3.20-1	输送短管 tube	1	119	3WF-2.6A.1-4	药箱下盖密封胶 Gasket	1	163	1E40F-3A.3-4	空滤器外罩 outside cover	1	
24	3WF-2.6A.11.2	连接梁组件 link frame	1	50	3WF-3-21	堵头 plug	1	87	3WF-2.6A.1-2	下轴隔板 plate	1	120	3WF-2.6A.1-3	药箱下盖密封胶 Gasket	1	165	1E40F-3A.3-3	滤芯 filter	1
25	GB/T 9074.4-M5X16	螺钉组合件 Bolt	8	51	3WF-3-22	摇臂轴 rocker shaft	1	89	3WF-3.20-2	喷雾盖板 misting plate	1	121	3WF-2.6.4-4	直管乙 pipe	1	166	1E40F-3A.3-1	空滤器内罩 inside cover	1
26	3WF-2.6.3	油门操纵杆 throttle cable	1	52	GB/T1235-14x3	O型密封圈 O-ring	1	90	3WF-3.7-1	喷盖密封垫 sealing washer	1	122	3WF-2.6.4-6	L型管 pipe	1	168	1E40F-3A.3-1	空滤器组架 Nozzle	1
29	3WF-3-5	手柄 Handle	2	53	GB/T 119-B6X55	销 pin	1	92	GB/818-M5X25	螺栓 Bolt	2	123	3WF-2.6.4-3	俯角接管 pipe	1	170	3WF-2.6.4.3.1	旋转喷头 Nozzle	1
30	3WF-2.6A.11-1-2	调速壳 Graduator	1	54	GB/T 896-9	挡圈 ring	1	93	3WF-2.6.4-1	风机弯头 Clamp	1	124	3WF-2.6.4-5	Y型管 pipe	1				
31	3WF-2.6.7.1	油门操纵杆 throttle dust rod	1	55	3WF-2.6.6.1	门体 shutter	1	94	3WF-3.17-1	药箱 Spray tank	1	129	3WF-3.19.5	2号卡环组件 Clamp	1				
32	3WF-3-15	接头体 connector	1	56	3WF-2.6.6	门体部件 shutter case	1	94	3WF-3.17-1A	药箱(SOL) Spray tank	1	130	3WF-3.17.2-2	药箱下盖密封胶 sealing washer	1				
33	GB/T 6170-M5	螺母 Nut	1	57	3WF-2.6.9.1	后蜗壳组合 Worm case	1	95	BG4.15-8	油管卡子 Clip	2	131	3WF-3.20.2-2	接管 link pipe	1				
34	3WF-2.6.7-7	油门拉杆 pulling rod	1	55,57,58,59	3WF-2.6.9	风机总成 engine assembly	1	97	GB/T818-M5X35	螺栓 Bolt	2	133	3WF-3.17.2-1	药箱下盖 lid	1				
35	3WF-2.6A-2	开口销 Split pin	1	58	GB/T1710-1-M8x35-12P	螺栓 bolt	2	98	SG79-8X2	管 Water tube	0.3m	134	3WF-3.20.2-1	接管压盖 connector lid	1				